



SKMEI 1721 Operation Manual



A . Features

- ★ 10 Digits LCD Display, Display Hour, Minute , Second , Month, Day, Year and Week
- ★ Daily Alarm and Chime hourly
- ★ 12 / 24H format selectable
- ★ Stopwatch time functions
- ★ Colorful EL backlight

B.Operational Manual





1. In the non-setting state, press B key to select the operation mode.
2. At any state , press C key colorful LED backlight for 2s.

2.Time mode

- ★ In normal time mode, Press D key to change the 12/24 h format selectable.

3.Daily Alarm Mode

- ★ When setting the alarm clock, in the Alarm Mode, press and hold A key to select " Hour " setting,, Press D key to adjust, then press A key to select "minute" setting and press D key to adjust.
- ★ In the Alarm Mode, press D key to turn on and off the alarm clock sign “” and the Chime hourly sign “”
- ★ When the alarm clock is turned on, when the alarm clock is set, the alarm clock will ring for 20 seconds and then stop automatically.
- ★ When the Chime hourly keeping is turned on, the alarm clock will sound when it reaches the hourly time .

4.Chronograph Mode

- ★ The display range of stopwatch is 23 hours 59 minutes 59.99 seconds.
- ★ The stopwatch starts to time in 0.01 seconds, and after 30 minutes, it will time in seconds.
- ★ When running , Press D key to Start running., Then Press D key to Stop running ; When stop, press A key to zero.
- ★ In stopwatch mode, press D key to start timing, press A Key to split Counting, press D Key to exit split Counting, enter stopwatch stop. Exiting the split Counting, press A Key to display all stopwatch time, press A Key to stopwatch to zero. When running, press B Key to return to the time display mode, stopwatch run behind it.
- ★ Press A key to enter split Counting and then press D key to exit split Counting and enter stop counting.
- ★ When exiting the split Counting, press A key to display all stopwatch time, and then press A key to stop running to zero; When running, press B key to return to the time display mode, and the stopwatch runs behind it.

5.Time setting mode

- ★ In time setting mode, "Second" flashing, press D key to adjust "second" to zero,
- ★ press A key to "hour" flashing, then press A key to enter the adjustment of "minute", "month", "day" and "week" in turn.
- ★ press D key to adjust while the seconds are in the range of 00 to 59 resets them to 00 the Minutes value remains unchanged.