


1103 operation:

Function:

1. In normal mode : display HOUR and MINUTES
2. Press S1 back to normal mode
3. Press S2 to convert time and date mode
4. Press S3 to show time and date, adjust the digital



Modes of watch



Time and Date Set

1. In normal mode, press S2 to enter into Time and Date setting mode, and the HOUR flashing, press S3 to adjust the hour.
2. Press S2 again, MINUTES flashing , press S3 to adjust the minutes
3. Press S2 again, MONTH flashing, press S3 to adjust the month
4. Press S2 again, DATE flashing, press S3 to adjust the date
5. Press S2 again, YEAR flashing, press S3 to adjust the year
6. Press S2 again, 12/24H flashing, press S3 to adjust 12/24H
7. Press S1 to back to normal time mode .