


# User Manual of SKMEI Model # 1164



## A . Features

- ★ 13 Digits LCD Display, Display Hour, Minute, Second, Year and Month, Date and Day.
- ★ Daily Alarm and Hourly Chime
- ★ 12 / 24H format selectable, Auto Calendar
- ★ 1/100 second Chronograph with split functions
- ★ Countdown Timer
- ★ Dual Time
- ★ EL backlight for 3s

## B . Operational Manual



1. At any mode, press A key, the EL back light for 3s

### 2. Real Time



- ★ Time Setting
  - a). While at Real Time Mode, press and hold C key for 2s to enter time setting state and "Second" will be flashing, press D key to zero; Press B key to select item as following sequence :

**Second → Minute → Hour → 12/24H format → Month → Date → Year**

- b). Press D key to adjust the flashing item,
- c). Press C key to return to Real Time Mode.

**Note:** if the seconds is in the range of 30" to 59", the minute will be added 1 minute while press D key to reset the second to Zero; if the seconds is in the range of 1" to 29", the minutes will stay no change.

### 3. Daily Alarm

In Alarm Mode, press D key repeatedly to turn the Alarm and Chime on/off as desired. Look for Alarm icon  and chime icon  for indication if the alarm and chime are on or off.

- ★ Alarm setting
  - Press and hold C key for 2s and the "Hour" is flashing, press D key to set the desired Hour; Then press B key and the "Minute" is flashing, press D key to set the desired minute.
- ★ The alarm sounds for about 20 seconds. Press any button to stop the alarm from sounding.

# User Manual of SKMEI Model # 1164

## 4. Chronograph

The display range of the chronograph is 23 hours, 59 minutes, 59.99 seconds.

- a) Once in this mode, press D key to start/stop the chronograph
- b) When the chronograph is stopped, press C key to reset timer to zero
- c) Press B key to return to Real Time Mode

### Split Time Function:

- a) While chronograph is running, press C key to activate the split time.
- b) Press D key to exit or stop split count
- c) When split time is stopped, press C key to display the last count; Press D key to reset counts to zero

## 5. Count down Timer mode

The display range of the timer is 23 hours, 59 minutes, 59 seconds. Press A to start/stop the countdown.

- ★ The timer alarm sounds for about 10 seconds when the counting down to 0:00:00.
- ★ The timer will be reset automatically to its starting value after the alarm sounds

### Timer Time Setting

- a) Once in this mode, press and hold C key, then press B key to select "Hour" or "Minutes" setting
- b) Press D key to adjust the flashing digit to desired time
- c) Press C key to confirm
- d) Press B key to return to Real Time Mode

### Timer operation

Press D key to Start/Stop counting ; Press C key to restart the value when counting stops.

## 6. Dual Time Mode

- ★ Dual Time setting  
In the Dual Time mode, Press and hold C key for 2s, then press B key to select "Minute" or "Hour" setting. Press D key to adjust the flashing item, Press C key to confirm the setting and back to Dual Time Mode.