


# 1543 LED WATCH USER MANUAL

## Function

- ★ Function: Year, Month, Day, Hour, Minutes, Seconds
- ★ In Normal Mode will be in stand by mode, and the watch will display nothing to save power.



## Mode convert

In normal mode, press S1 to convert the mode as following:

Normal mode → Date display mode → Seconds display mode → Normal mode

## Operation

- ① In normal mode, hold S2 for 2s to enter time and date mode, and "Hour" flashing, press S1 to adjust Hour.
- ① press S2 again, then "Minutes" flashing, press S1 to adjust Minutes.
- ① Press S2 again, then "Year" flashing, press S1 to adjust Year.

Remark : Set the year from 2000-2099 , Display : Y 00 means 2000 year. (Digits display: 00~99 )

- ① press S2 again, then "Month" flashing, press S1 to adjust Month.
- ① press S2 again, then "Date" flashing, press S1 to adjust Date.

**After set all the data, press S2 to exit. Or no any operation for 5s will back to stand by mode.**