



SKMEI 1623 Operation Manual



A.Features:

- ★ 10 Digits LCD Display, Display Hour, Minute, Second, Month, Day and Week
- ★ Daily Alarm and Chime hourly
- ★ 12/24H format selectable
- ★ Stopwatch timing function
- ★ LED backlight

B.Operational Manual:



Press B key to switch to different mode.

Press A key the LED backlight will last for 2 seconds.

1.Real Time

- ★ In Real Time Mode , press D key to switch to 12H or 24H display format.

2.Daily Alarm

- ★ Alarm setting: under Alarm Mode, Press C key for alarm setting, the "Hour " is flashing , press D key to adjust the hour ; Press C key, the "Minute " is flashing, press D key to adjust the minute. Press C key to confirm, Press B key to switch to Real Time mode.
- ★ Under Alarm Mode, Press D Key to turn on/off Alarm ("||||") or Chime ("A")
- ★ When Daily Alarm is on, the alarm sound will last 20 seconds at the setting time then stop.
- ★ When Chime Hourly is on, it will sounds one time at Hourly Time.

3.Chronograph

- ★ The display range of the Chronograph is 23 hours, 59 minutes, 59.99 seconds;
- ★ Press D key to Start/Stop running ; When stop, press C key to reset the date to zero.
- ★ When running ,press C key to split count,. Then press D key to exit split count and stop counting ; press C key to display all counts, press C key again to reset the count to zero ;
- ★ When the count is running, press B key to back to Real Time Mode, the count is still running.

4.Time Setting

- ★ Under Time setting mode, the “second” is flashing, press D key to reset the “second” to zero, Press C key to select item as following sequence:
Hour-----Minute -----Second-----Month-----Day-----Week
- ★ Press D key to adjust the flashing item.
- ★ Press D key while the seconds are in the range of 00 to 59, the minute will remain unchanged while the second returns to 00.