




FEATUR

- ★ Normal Time: Hour, Minute, Second, Month, Date and Week;
- ★ 12/24hour format;
- ★ Daily alarm & hourly chime
- ★ Snooze function
- ★ 1/100 second Chronograph with split functions;
- ★ Dual time;
- ★ Countdown function, to: 23:59:59;
- ★ 3 second EL backlight


FUNCTIONAL

CHANGE FUNCTION

- ★ Under Time Mode, press B key switch the following mode: Time Mode → Alarm Mode → Chronograph Mode → Countdown Mode → Dual Time Mode;




- ★ Under Time Mode, press C key switch the 12/24 hour format;



- ★ Under any mode, press D key to be on EL backlight for 3 seconds.

TIME/DATE SETTING

- 1、Under Time Mode, press and hold A key for 2 seconds to enter the time setting mode, “second” flashing;
- 2、Press B or C key to change setting items: second → minute → hour → day → month → year;




- Press D key adjust the setting items, press and hold D key to rapidly adjust;
- After setting, press A key to exit setting mode.


Note: Adjust year, month, day, the weekday will updated automatically.

ALARM MODE

- Under Alarm Mode, press D key to change items: Alarm 1 → Alarm 2 → Alarm 3 → Alarm 4 → Alarm 5; press C key to open corresponding alarm function;




- Under Alarm Mode, press C key to open: Alarm mode → Alarm 1 → Alarm 1 ON → Snooze ON;




Note: The Snooze function just can be opened at Alarm 1.

- Under Alarm Mode, press D key to enter hourly chime interface, press C key ON/OFF hourly chime;




- Under Alarm Mode, press and hold A key for 2 seconds enter alarm setting mode, “hour” flashing;
- Press B or C key to change setting items: hour → minute



- Press D key adjust the setting items, press and hold D key to rapidly adjust;
- After setting, press A key to exit setting mode.


CHRONOGRAPH MODE



- Under Chronograph Mode, press C key to start/ stop chronograph, When the chronograph stop, press A key to reset timing data.
- During the chronograph, press A key to turn on the split time function, display “SPL” on the screen. The chronograph continue and then press A key to return to the chronograph timer again.
- Stopwatch reaching the maximum (59’59”99), then on-alarm prompted to restart the chronograph.


COUNTDOWN TIMER

Range: 23:59.59



COUNTDOWN SRTTING

- Under Countdown Mode, press and hold A key for 2 seconds enter the setting mode, “hour” flashing;
- Press B or C key to change setting items: hour→minute;



Countdown Mode


- Press D key adjust the setting items, press and hold D key to rapidly adjust;
- After setting, press A key to exit setting mode.
- When countdown reach to 00:00.00, the countdown icon disappears and 15 seconds alarm reminders, press any key to stop the alarm.
- When stop the alarm, display the countdown setting value.

DUAL TIME

Dual time setting

- Under Dual Time Mode, press and hold A key for 2 seconds to enter the dual time setting mode, “hour” flashing;

3、 Press B or C key to change setting items: hour→minutes;



Dual Time Mode

4、 Press D key adjust the setting items, press and hold D key to rapidly adjust;
After setting, press A key to exit setting mode.