



# 时刻美 10Y 电子表通用说明书



## A. 功能简介:

- ◆ 6位计时功能, 显示时、分、秒、日、月、星期
- ◆ 响闹及整点报时
- ◆ 12/24时制选择
- ◆ 1/100秒表
- ◆ 两地时间
- ◆ EL背光
- ◆ 10年寿命电池

## B. 产品功能模式:



- ◆ 1.任意模式下按A键或者D键三秒EL灯亮。

## 2. 时间模式:

- ◆ 在时间模式下, 按C键两秒, 进入时间设置模式, 此时“秒”闪动, 按B键调整“秒”归零; 按C键“时”闪动, 再按C键依次选择“分”、“12/24时制”, 在对应元素闪动时, 按B键进行调整。
- ◆ 在设置“秒”时, 若秒数值于30至59之间, 在秒数值回到00的同时, 分数值亦会增加1; 若秒数值是于00至29之间, 分数值则保持不变。
- ◆ 在设置模式下, 当对应元素闪动时, 按B键进行调整, 被设置项目可快速递增。
- ◆ 在设置模式时, 若在60秒无按键操作, 则会退出时间设置模式, 返回时间模式。

## 3. 日期模式:

- ◆ 在日期模式下, 按C键两秒, 进入日期设置模式, 此时“月”闪动, 按C键依次选择“日”、“星期”, 在对应元素闪动时, 按B键进行调整。
- ◆ 在设置模式下, 当对应元素闪动时, 按B键进行调整, 被设置项目可快速递增。
- ◆ 在设置模式时, 若在60秒无按键操作, 则会退出日期设置模式, 返回日期模式。

## 4. 闹钟模式:

- ◆ 在闹钟模式下, 按C键两秒, 进入闹钟设置模式, “时”闪动, 再按C键依次选择“分(十位)”、“分(个位)”、“ALM/SIG(闹钟/整点报时)开关”, 按B键进行调整。
- ◆ 设置“ALM/SIG开关”时, 顺序如下:  
ALM/SIG 开 → ALM/SIG 关
- ◆ 在开启闹钟的情况下, 到达闹钟设定时间时, 闹声会响闹20秒后自动停止。
- ◆ 在设置模式下, 当对应元素闪动时, 按B键进行调整, 被设置项目可快速递增。
- ◆ 在设置模式时, 若在60秒无按键操作, 则会退出闹钟设置模式, 返回闹钟显示模式。


## 5. 两地时间:

- ◆ 在两地时间模式下, 按C键两秒, 进入时间设置模式, 此时“时”闪动, 再按C键依次选择“分”、“12/24时制”, 在对应元素闪动时, 按B键进行调整。
- ◆ 在设置模式下, 当对应元素闪动时, 按B键进行调整, 被设置项目可快速递增。
- ◆ 在设置模式时, 若在60秒无按键操作, 则会退出两地时间设置模式, 返回两地时间显示模式。

## 6. 秒表模式:

- ◆ 在秒表模式下, 按一次C键开始执行跑秒, 再按一次C键跑秒停止, 按C键两秒秒表归零。

# SKMEI 10Y Digital Watch User Manual



## A. Features:

- ◆ 6 Digits LCD Display, Display Hour, Minute, Second, Month, Day and Week
- ◆ Daily Alarm and Chime hourly
- ◆ 12 / 24H format selectable
- ◆ 1/100 second Chronograph
- ◆ Dual time
- ◆ EL backlight
- ◆ 10 years Battery

## B. Operational Manual:



- ◆ 1. At any state, press A or D key, EL backlight will light up.

## 2. Real Time:

- ◆ Press C key for 2 seconds to enter into the time setting mode. "Second" flashing when loading, press B key to zero; Press C key to select the blinking digit according to the following sequence: Hour → Minute → 12H/24H. Press B key to adjust the flashing item.
- ◆ While the seconds are in the range of 30 to 59 resets them to 00 and adds 1 to the minutes. In the range of 00 to 29, the minutes are unchanged.
- ◆ Press B key to adjust Time and Hold B key to adjust quickly.
- ◆ If there is no key operation for 60 seconds, Setting Mode will be exit and returned to Real Time Display Mode.

## 3. Date Mode:

- ◆ Press C key for 2 seconds to enter into the date setting mode "Month" flashing when loading. Press C key to select item as following sequence: Day and Week. Press B key to adjust the flashing item.
- ◆ Press B key to adjust Date and Hold B key to adjust quickly.
- ◆ If there is no key operation for 60 seconds, Setting Mode will be exit and returned to Date Display Mode.

## 4. Daily Alarm:

- ◆ Press C key for 2 seconds to enter into the alarm setting mode, "Hour" flashing. Press C key to select item as following sequence: "Minute (ten's digit)", "Minute (unit's digit)", "ALM/SIG(Alarm/Chime)" switch.
- ◆ Press B key to adjust the flashing item.
- ◆ When setting "ALM/SIG" switch, gradation as follows:  
ALM/SIG ON → ALM/SIG OFF
- ◆ There will be 20s alert when alarm time is over.
- ◆ Press B key to adjust Alarm and Hold B key to adjust quickly.
- ◆ If there is no key operation for 60 seconds, Setting Mode will be exit and returned to Alarm Display Mode.

## 5. Dual time:

- ◆ Press C key for 2 seconds to enter into the Dual time setting mode, "Hour" flashing when loading, Press C key to select item as following sequence: Minute → 12H/24H
- ◆ Press B key to adjust time and Hold B key to adjust quickly.
- ◆ If there is no key operation for 60 seconds, Setting Mode will be exit and returned to Dual Time Display Mode.

## 6. Chronograph:

- ◆ Press C key to Start/Stop running; When stop, press C key for 2 seconds to return to zero.