


SKMEI 1681 Watch Operation Manual




Features

- ③ Time perpetual calendar function.
Time limit : Jan. 1th, 2000 ~ Dec. 31th 2099, 12/24 hour option ;
Week : English language, automatically displayed ;
- ③ Alarm function. Alarm time : 20 seconds ;
- ③ Hourly time signal function.
- ③ Stopwatch function: Maximum to : 23 : 59' 59" ;
- ③ Countdown function: Maximum to : 24 : 00' 00" ;
- ③ Automatically detect the ambient temperature and wrist temperature ;
- ③ Detect human body temperature ;
- ③ 7 groups of historical temperature data query ;
- ③ LED EL backlight

Function Instructions

- ③ In time mode, press B key switch to following modes: Time mode → Alarm mode → Countdown mode → Stopwatch mode
- ③ Detect Body Temperature mode
- ③ In time mode, Press D key two times to switch to fast detecting temperature mode, wait 20 seconds, get the latest date, press B key to return to time mode.

Remarks: Wear watch for ten minutes before detecting your body temperature;



Time Mode

- ③ Press C key to setting modes : date-Ambient temperature.
- ③ Press and hold C key for 2 seconds to enter time setting state.
- ③ Press B key to setting items : seconds → hour → minute → year → month → day → Power saving function → temperature unit °C / °F (C stands for Celsius, F stands for Fahrenheit);

- ③ At time setting state, press A key to switch 12/24 hours , press D key to exit the setting.
- ③ Press D key to adjust setting, **holding D key can quickly adjust .**
- ③ Adjust the year, month, and day. After exiting the setting, the week will be automatically updated .
- ③ In time setting state, no key operation for 2-3 minutes, automatically exit the setting state and return to the time display mode.
- ③ Turn on power saving function, the screen will automatically turn off without key operation in 10 minutes, and press any key to wake up the display.

Alarm Mode

- ③ In time mode, press B key to enter alarm mode
- ③ In alarm mode, press D key to quickly turn on / off the alarm and the hourly time signal
- ③ In alarm display mode, it will not automatically return to the time display mode without key operation.
- ③ Press and hold C key for 2 seconds to enter the corresponding alarm setting state. Under setting state, press B key to setting : hour → minute → month → day, short press C key to exit and save setting, as the picture shows (the red part in the picture represents flashing).
- ③ Enter the alarm setting state, automatically turn on the alarm, display the alarm icon.
- ③ Press D key to adjust the setting item, **holding D key can quickly adjust.**
- ③ No key operation for 2-3 minutes, automatically exit the alarm setting state and return to the alarm display mode.
- ③ When reach the alarm time, the alarm icon flashing, 20 seconds alarm sounds, and "BIBIBIBI" sounds four times per second.

Countdown Mode

- ③ In time mode , press B key two times switch to countdown interface, display countdown : 00 : 00.00
- ③ Press and hold C key for 2 seconds enter countdown setting status, press B key to setting items: hour → minute, and press C key to exit setting, as the picture shows ;
- ③ Short press D key to adjust setting, **holding D key can quickly adjust.**
- ③ Press C key to turn on / off the automatic repeat function.
- ③ In the countdown setting state, no key operation for 2-3 minutes, automatically exit the setting state and return to the countdown mode.
- ③ Press D key to start / pause countdown. The countdown starts and the icon flashes. Stop countdown, icon disappears .
- ③ The countdown is paused, the icon disappears, press C key to return to display the countdown setting .
- ③ The countdown ends, display 00: 00.00, the icon continue flashing, 10 seconds alarm sounds , press any key to stop the alarm, and return to countdown setting .
- ③ **In countdown mode,** without key operation, it will not automatically return to time display mode.

Stopwatch Mode

- ③ In time mode , press B key three times to switch to the stopwatch mode and display the initial value of the stopwatch : 00 : 00'00"00.
- ③ Press D key to start / pause running seconds, press C key to start SPL. When the stopwatch is paused, press C key to clear.
- ③ When the stopwatch reaches the maximum value (23: 59'59 " 99), there is no alarm prompt, continue to start the stopwatch from 00'00"00