


SKMEI 1368 User Manual




Features:


- ★ Normal Time: Hour, Minute, Second, Month, Day and Week;
- ★ 12/24hr format;
- ★ Daily alarm & hourly chime
- ★ Snooze function
- ★ 1/100 second Chronograph with split functions;
- ★ Dual time;
- ★ Countdown function, to: 23:59:59;
- ★ EL backlight

Operational Manual

In normal time mode, press B key switch the following mode: Time mode → Alarm mode → Stopwatch → Dual mode → Countdown;




- ★ In time mode, press D key change the 12/24 hour format;



- ★ At any mode, press A key EL backlight on for 3 seconds.

Time Mode Setting:


- ★ In time mode, press and hold C key enter the time setting mode, “second” flashes;
- ★ Press B key to change setting items: second → hour → minute → year → month → day;




- * Press D key adjust the setting items, press and hold D key to rapid adjust;
- * After setting, press C key exit setting mode.
- * Note: Adjust year, month, day, the weekday will updated automatically.

Alarm Mode Setting:

- * In alarm mode, press C key order to open: daily alarm→Snooze function;



- * Under alarm mode, press D key enter hourly chime; press C key ON/OFF hourly chime;




- * Under alarm mode, press and hold C key enter alarm setting mode, “hour” flashes;
- * Press B key to change setting items: hour→minutes→month→day;



- * Press D key adjust the setting items, press and hold D key to rapid adjust;
- * After setting, press C key exit setting mode.


Stopwatch Mode Setting:



- * In stopwatch mode, press D key start/ stop stopwatch, When the stopwatch stops the clock, press C key reset timing data.
- * During the stopwatch timer, press C key turn on the split time, display “SPL” on the screen. The stopwatch continued to time, press C key return to the stopwatch timer again.
- * Stopwatch reaching the maximum(59’59’’99), the non-alarm prompted to restart the stopwatch timer.

Dual time setting:


- ★ In dual time mode, press and hold enter the dual time setting mode, “hour” flashes;
- ★ Press B key to change setting items: hour→minutes;




- ★ Press D key adjust the setting items, press and hold D key to rapid adjust;
- ★ After setting, press C key exit setting mode.

Countdown Mode Setting:

Range: 23:59.59



- ★ In countdown mode, press and hold C key for 2 seconds enter the countdown setting mode, “hour” flashes;
- ★ Press B key to change setting items: hour→minutes;



- ★ Press D key adjust the setting items, press and hold D key to rapid adjust;
- ★ After setting, press C key exit setting mode.
- ★ When countdown reach to 00:00.00, the countdown icon disappears and 15 seconds alarm reminders, press any key to stop the alarm.
- ★ When stop the alarm, display the countdown setting value.